



TIOGA™ 12'x8'

Instructions apply to Part Number 9273C128

When You Are Ready To Set Up Your Tent

- Select a level campsite clear of rocks, branches and other hard or sharp objects.
- Do not set up your tent under trees.
- For best results in windy conditions, do not position the door of tent into the wind.

(3) Main
Tent Poles

(1) Rainfly
Pole

POLE ASSEMBLY PARTS


Part No. 9273C121

Part No. 9273C122

Rainfly Part No. 9273C123

1 Layout & Positioning of Tent, Pole Assembly

- Layout and position tent with doors facing desired direction. (illus. 1)
- Unzip doors.
- Stake down tent corners only, using the rings at the end of the stake loops. Keep the floor taut. (illus. 2)
- Assemble Frame Poles by interlocking shock-corded poles. This will make three long poles.
- Insert the poles diagonally into three Pole Sleeves. (illus. 1)



Insert poles
through
three pole
sleeves


illus. 2 Tent stake
through ring

2 Connect Frame to Tent

- Insert one end of main tent pole end onto pin of pin & ring system, at tent corner. (illus. 4)
- Go to opposite end of pole and gradually apply pressure to the pole forming an arch until you are able to insert the pin into the pole.
- Repeat for second and third poles.

illus. 3



Tent frame
set-up



illus. 4
Insert pole end onto
pin & ring

3 Attach Rainfly

- Assemble rainfly pole by interlocking shock-corded pole.
- Insert rainfly pole into reinforced pockets located at the center edges of the underside of rainfly. (illus. 5), (illus. 6)
- Tie underside of rainfly to the rainfly pole with frame ties. (illus. 5)
- Drape rainfly over tent frame, pole side down. Rainfly pole should point out over front and back side of tent.
- Connect the six elastic loops with “S” hooks, (found at the rainfly corners) to the fabric loops near frame clips.
- Secure rainfly with frame ties located on underside of rainfly. (illus. 7)
- Stake out tent with two side guylines. (illus. 7)



illus. 6 Insert rainfly pole piece into pocket on underside of rainfly.

Attach and stake out guylines. One each side.



illus. 7 Completed tent with rainfly. Note where rainfly pole pockets, “D” rings, and under ties are located.

Things You Should Know

- Under certain conditions (cold weather, high humidity, etc.) condensation will form on the inside surfaces of your tent. Condensation is caused by water vapor from your breath, perspiration, or any wet clothing inside your tent. It is NOT LEAKAGE through the tent fabric. It can be minimized by removing wet clothing from your tent and by providing good ventilation through the tent.
- Never store tent, even for a short period of time, without drying it thoroughly and brushing off caked dirt. Do not pack stakes or poles inside your tent. Use a separate storage bag.
- STAKES SHOULD BE REMOVED BY PULLING ON THE STAKE ITSELF. NEVER PULL ON THE TENT FABRIC OR TENT STAKE LOOP TO REMOVE STAKE.
- TENT POLES SHOULD NOT BE LEFT TELESKOPED TOGETHER DURING STORAGE.
- Seam sealer has not been provided with your tent. For additional protection we recommend seam sealing your tent prior to camping. Seam sealer may be purchased through your local retailer or at your local sporting goods store.

- Do not leave your tent set-up for weeks at a time, be aware that exposure to the ultraviolet rays of the sun can seriously damage material and/or cause it to become discolored.

WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC. This tent meets the flammability requirements of CPAI-84. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.



THE COLEMAN CO., INC.

3600 N. Hydraulic • Wichita, Kansas 67219

1-800-835-3278 • www.coleman.com

MADE IN CHINA